



The negative terminal of the external, 24 Volt DC, power supply must be connected to the "Chassis Gnd" terminal of the mixer. DO NOT CONNECT the power supply ground to any other terminal on the 884+.

Ivie CC-884 & KD-884 to Ivie 884+ Wiring Diagram