

NOV-88 CONTROL SYSTEM INSTALLATION GUIDE & N8A "Student Bldg" Logic Tables



NOV88 "Student Building" Equipment List for Ivie Technologies Products

Chapel "A"	CC"A"	CC"B"	Chapel "B"
------------	-------	-------	------------

Qty	Product	Description
1	NOV-88	Logic controller
2	884+	Matrix mixers with Standard ROM firmware (NOT LDS firmware)
2	626	DSP
2	CP-884	Chapel control
2	CS-884	Satellite control
2	CC-884	Cultural Center control (In addition to supplied 78C-6)
2	IM-10	Sacrament microphones
2	78C-6	Mix bus jumper cables
3	IR-I	Infrared door sensors

SPECIAL NOTE # 1
ANSW software "Switch Type"
settings (Edit, Switch Type) for ALL
switches on 884 mixers MUST be set
to "M" momentary. Other (A) setting
WILL NOT WORK







NOV88 "California MS-88" Equipment List for Ivie Technologies Products

Chapel "A"	CC "A"	CC "B"	CC "C"
------------	--------	--------	--------







Qty	Product	Description
1	NOV-88	Logic controller
2	884+	Matrix mixers with Standard ROM firmware (NOT LDS firmware)
2	626	DSP
1	CP-884	Chapel control
1	CS-884	Satellite control
3	CC-884	Cultural Center control
1	IM-10	Sacrament microphones
2	78C-6	Mix bus jumper cables (In addition to supplied 78C-6)
3	IR-1	Infrared door sensors

SPECIAL NOTE # 2
On both 884+ mixers, preset # 13 should
be programmed for Auto / Manual
operation and preset # 14
should be programmed for
Satellite operation

NOV-88 to Chapel and Cultural "A" Units




* NOTE: ALL +24VDC connections are made to the contractor supplied +24VDC power supply. Refer to the Ivie Drawing titled "Star Grounding and Power Supply."




Chapel "A" Output C-Center "A" Output Chapel "B" Output C-Center "B" Output


NOV-88 to Chapel & Cultural "B" Units ("Student" plan)




Note: No Jumper is installed to configure it for the "Student" plan.




* NOTE: ALL +24VDC connections are made to the contractor supplied +24VDC power supply. Refer to the Ivie Drawing titled "Star Grounding and Power Supply."







CHAPEL "B" Bishop's



CHAPEL "B" Satellite





CHAPEL "B" Cultural Center



884+ "A" - Presets


626 "A" - Presets




884+ "B" - Presets

626 "B" - Presets


Connections to 884+ "B"



(Label Color is Orange)









(Label Color is Pink)



(Label Color is White)


Connect to 884+ "A" Mixer Mstr Output "C"

NOV-88 to "A" & "B" Preset Connections




Connections to System "A"


(884+ "A" Green Color Terminal Block)



(884+ "A" Red Color Terminal Block)




(626 "A" PRESET Terminal Block)




Connections to System "B"


(884+ "B" Green Color Terminal Block)









(884+ "B" Red Color Terminal Block)




(626 "B" PRESET Terminal Block)



NOV-88 RELAY Connections



IMPORTANT NOTE: ALL RELAYS **must** have a "snubber" diode placed across the coil connections as shown. This diode must be a 1N4001 or any diode with a greater PIV and equal current rating. FAILURE TO USE THE PROPER DIODE WILL CAUSE DAMAGE TO THE NOV88 WHICH WILL REQUIRE NON-WARRANTY FACTORY SERVICE



Only required in the "Student" plan. Not used in the "MS-88" plan.

To +24 Vdc of power supply

Star Grounding
- a star grounding system **MUST** be employed for proper operation.

Ground Link In Place
(Connected)

NOV-88 Controller

78C-6 Jumper cables.
4 required

Ground Link
Removed

884+ Mixer

Must have Standard 884+ ROM
(NOT LDS ROM)

Ground Link
Removed

884+ Mixer

Must have Standard 884+ ROM
(NOT LDS ROM)

Ground Link
Removed

626 DSP

Ground Link
Removed

626 DSP

24Vdc power supply,
contractor supplied

To +24VDC CP-884 "A"
To +24VDC CS-884 "A"
To +24VDC CC-884 "A"
To +24VDC CP-884 "B"
To +24VDC CS-884 "B"
To +24VDC CC-884 "B"
To PWR Relay
To SAT "A" Relay
To SAT "B" Relay
To Organ Relay

The negative terminal of the 24 Vdc power supply **MUST** be connected to the Star Ground on the NOV88. Either the Audio Gnd or Chassis Gnd of the NOV88 may be used for this connection

**Star Grounding &
Power Supply**

Ivie Technologies

NOV88

AudioNet Controller


CP-CC-CC-CP Logic Tables

(“N8A” – Student Building)


8/24/2000 – Rev 3




Mode - 1




Mode - 2




Mode - 3




Mode - 4




Mode - 5




Mode - 6




Mode - 7




Mode - 8




Mode - 9




Mode - 10




Mode - 11




Mode - 12




Mode - 13




Mode - 14




Mode - 15




Mode - 16




Mode - 17




Mode - 18




Mode - 19




Mode - 20




Mode - 21




Mode - 22




Mode - 23




Mode - 24




Mode - 25




Mode - 26




Mode - 27




Mode - 28




Mode - 29




Mode - 30




Mode - 31




Mode - 32






Mode - 33







MODE - 1






RECORD-B

RECORD-A








MODE - 2






RECORD-B

RECORD-A








MODE - 3









RECORD-B
RECORD-A












MODE - 4






ORGAN

Organ








MODE - 6





RECORD-B

RECORD-A








MODE - 7




PSET - 2




PSET - 4






PSET - 4



PSET - 7






MODE - 8






RECORD-B

RECORD-A








MODE - 9






RECORD-B

RECORD-A








MODE - 10






RECORD-B

RECORD-A








MODE - 11






RECORD-B

RECORD-A







MODE - 12






RECORD-B

RECORD-A








MODE - 13






RECORD-B

RECORD-A








MODE - 14






RECORD-B

RECORD-A







MODE - 15








RECORD-B
RECORD-A






CP-A	CC-A	CC-B	CP-B

MODE - 16







MODE - 17






RECORD-B

RECORD-A







MODE - 18






RECORD-B

RECORD-A








MODE - 19







RECORD-B


RECORD-A










MODE - 20








MODE - 21







MODE - 22






NOTE: NO TRACKING LEVEL IN CC-B.
ADJUST LEVEL AS DESIRED
IN PRESET 3 (884-B)








MODE - 23





RECORD-B

RECORD-A







MODE - 24






RECORD-B
RECORD-A








MODE - 25






RECORD-B

RECORD-A







MODE - 26





RECORD-B

RECORD-A






MODE - 27




PSET - 2



PSET - 4


RECORD-B

RECORD-A






PSET - 5

PSET - 7





MODE - 28






RECORD-B

RECORD-A







MODE - 29




RECORD-B

RECORD-A








ORGAN

Organ






MODE - 30







MODE - 31






RECORD-B

RECORD-A







MODE - 32






RECORD-B

RECORD-A















MODE - 33




RECORD-B
RECORD-A




884-A PRESETS




USED BY MODES: 8, 13, 14, 15, 16, 29




USED BY MODES: 1, 2, 4, 6, 9, 10, 11, 12
17, 18, 20, 21, 23, 25, 26
28, 30, 31, 32, 33






USED BY MODES: 3, 19




USED BY MODES: 22




USED BY MODES: 5, 7, 24, 27




Mode - 1




Mode - 2




Mode - 3




Mode - 4




Mode - 5




Mode - 6




Mode - 7




Mode - 8




Mode - 9




Mode - 10




Mode - 11




Mode - 12




Mode - 13




Mode - 14




Mode - 15




Mode - 16




Mode - 17




Mode - 18




Mode - 19




Mode - 20




Mode - 21




Mode - 22




Mode - 23




Mode - 24




Mode - 25




Mode - 26




Mode - 27




Mode - 28




Mode - 29




Mode - 30




Mode - 31




Mode - 32



Mode - 33




EQA - PRESET #1




7-3A 1

#1
PSET -


EQA - PRESET #2




7-3A 2

#2
PSET -


7-3A 4

#3
PSET -


7-5A 1

#4
PSET -


7-5A 4

#5
PSET -


7-6 1

#6
PSET -


7-6 4

#7
PSET -

8A-8B 2


#8
PSET -

9A-9B 3

#9
PSET -


10A-10B 3

#10
PSET -




4-1 2

PSET - #1




4-1 1

PSET - #2




4-1 4

PSET - #3




2A-2B 3

PSET - #4




3B-3C 8

PSET - #5




5B-1 1

PSET - #6




5B-1 4

PSET - #7




9C-1 5

PSET - #8



9C-1 7

PSET - #9



10C-100 6

PSET - #10

<u>MODE</u>	<u>884-A</u>	<u>884-B</u>	<u>EQ-A</u>	<u>EQ-B</u>	
0	0	0	15	15	
1	0	1	15	1	
2	0	1	15	4	
3	0	2	1	5	EQ "A" Relay
4	0	1	15	2	
5	2	4	4	6	
6	0	1	15	3	
7	2	4	4	7	
8	1	0	6	15	
9	1	1	6	1	
10	1	1	6	4	
11	1	1	6	2	
12	1	1	6	3	
13	1	0	2	15	
14	1	0	8	15	
15	4	0	9	8	EQ "B" Relay / Organ Relay
16	4	0	10	10	EQ "B" Relay / Organ Relay
17	1	1	2	1	
18	1	1	2	4	
19	3	2	3	5	EQ "A" Relay
20	1	1	8	1	
21	1	1	8	4	
22	4	3	9	9	EQ "B" Relay
23	1	1	2	2	
24	2	4	5	6	
25	1	1	8	2	
26	1	1	2	3	
27	2	4	5	7	
28	1	1	8	3	
29	1	0	7	15	
30	1	1	7	1	
31	1	1	7	4	
32	1	1	7	2	
33	1	1	7	3	


```
;      NOV88_A - Mode to Preset Table
public n8a_p
n8a_p:
```

;mode		884-A	884-B	EQ-A	EQ-B	
;----		-----	-----	-----	-----	
am000:	db	00h,	00h,	15,	15	;
am001:	db	00h,	80h,	15,	1	;
am002:	db	00h,	80h,	15,	4	;
am003:	db	00h,	40h,	1,	5	;
am004:	db	00h,	80h,	15,	2	;
am005:	db	40h,	10h,	4,	6	;
am006:	db	00h,	80h,	15,	3	;
am007:	db	40h,	10h,	4,	7	;
am008:	db	80h,	00h,	6,	15	;
am009:	db	80h,	80h,	6,	1	;
am010:	db	80h,	80h,	6,	4	;
am011:	db	80h,	80h,	6,	2	;
am012:	db	80h,	80h,	6,	3	;
am013:	db	80h,	00h,	2,	15	;
am014:	db	80h,	00h,	8,	15	;
am015:	db	10h,	00h,	9,	8	;
am016:	db	10h,	00h,	10,	10	;
am017:	db	80h,	80h,	2,	1	;
am018:	db	80h,	80h,	2,	4	;
am019:	db	20h,	40h,	3,	5	;
am020:	db	80h,	80h,	8,	1	;
am021:	db	80h,	80h,	8,	4	;
am022:	db	10h,	20h,	9,	9	;
am023:	db	80h,	80h,	2,	2	;
am024:	db	40h,	10h,	5,	6	;
am025:	db	80h,	80h,	8,	2	;
am026:	db	80h,	80h,	2,	3	;
am027:	db	40h,	10h,	5,	7	;
am028:	db	80h,	80h,	8,	3	;
am029:	db	80h,	00h,	7,	15	;
am030:	db	80h,	80h,	7,	1	;
am031:	db	80h,	80h,	7,	4	;
am032:	db	80h,	80h,	7,	2	;
am033:	db	80h,	80h,	7,	3	;